

## LAMB COMPONENTS TORQUES SPECS

### ROTORS

#### CAST IRON

1300A- 9.5 CAST IRON ROTOR PLEASE TORQUE NEW HARDWARE TO 75 INCH POUNDS.  
WHEN INSTALLING NEW ROTORS USE LOCTITE #272

1301- 11.5 CAST IRON ROTOR PLEASE TORQUE HARDWARE TO 80-100 INCH POUNDS AND  
USE #272 LOCTITE

#### STEEL

1300S- 10" STEEL ROTOR PLEASE TORQUE NAS1291X3 NUTS TO 35 INCH POUNDS AND USE  
#272 LOCTITE

1308-11" STEEL ROTOR PLEASE TORQUE NAS1291X3 NUTS TO 30 INCH POUNDS AND USE  
#272 LOCTITE

1309- 11.5 STEEL ROTORS PLEASE TORQUE NAS1291X3 NUTS TO 30 INCH POUNDS AND USE  
#272 LOCTITE

#### CARBON

1300B- 10" CARBON ROTOR PLEASE TORQUE TO 35 INCH POUNDS USE #272  
LOCTITE

1302-1- 11" CARBON ROTOR INSTALLATION: PLEASE TORQUE CARBON ROTOR  
HARDWARE TO 35 INCH POUNDS - USE #272 LOCTITE

1302- 11.5" CARBON ROTOR INSTALLATION: PLEASE TORQUE CARBON ROTOR  
HARDWARE TO 35 INCH POUNDS - USE #272 LOCTITE